

ABP 12090 PARAPET BRACKET SET UP INSTRUCTIONS

- 1.) REMOVE LOCKING PIN AND ADJUST RACK JOINT TO FIT PARAPET WALL WITHIN THE 3" ADJUSTMENT LIMIT AND REINSERT LOCKING PIN AND LOCK CLASP.
- 2.) INSTALL BRACKET TO PARAPET WALL BY KEEPING Y-LEGS TO OUTSIDE OF PARAPET WALL AND ADJUSTMENT LEG TO INSIDE OF PARAPET WALL. RACK JOINT AND Y-LEGS REST FIRMLY ON TOP OF PARAPET WALL.
- 3.) TIGHTEN ADJUSTMENT SCREW UNTIL REAR AND FRONT RAILS ARE TIGHT AGAINST OUTSIDE AND INSIDE OF PARAPET WALL. INSTALL TWO 3/16" TAPCON SCREWS THROUGH HOLES PROVIDED IN RAIL AND TIGHTEN SECURELY TO INSIDE OF PARAPET WALL.
- 4.) INSERT GUARD RAIL POST THROUGH POST HOLDER LETTING POST REST ON THE ROOF'S SURFACE.
- 5.) REPEAT ASSEMBLIES EVERY SIX TO EIGHT FEET ON CENTER
- 6.) INSTALL 2"X4" GUARD RAILS THROUGH HOLES PROVIDED. POST IS AUTOMATICALLY SET TO OSHA STANDARDS.